

Trampoline leg spring



Details

These springs are used to hold the leg braces in position when in use and to hold the leg brace against the trampoline when folded. Four are required per trampoline.