

Nylon bench hook



Details

These two-part nylon bench hooks are screw fixed to the underside of one or both ends of timber benches to allow for linking and bridging activities using the benches. Two are required for each bench end.

Our hooks are now supplied only in our standard red colour so if you have an existing bench with our old natural off-white colour you may wish to purchase two hooks so they match. There is no change in dimensions so colour mismatched hooks will not have performance implications